SEMAK

SEMAK HOT DOG COOKER & SPIKER – MODEL HD3T

OPERATION AND WARRANTY BOOKLET

SEMAK AUSTRALIA: FACTORY 18, 87-91 HALLAM SOUTH ROAD, HALLAM VIC 3803

PH +61 3 9796 4583 FAX +61 3 9796 4586 WEB WWW.SEMAK.COM.AU

Table of Contents

General Safety Instructions for All Semak Products 4

Safety Instructions 5

Operating Instructions for the Semak Hot Dog Cooker & Bun Spiker 6

Cleaning Instructions for the Semak Hot Dog Cooker & Bun Spiker 7

Spare Parts for the Semak Hot Dog Cooker & Bun Spiker 7

Service & Maintenance 8

Electrical Compliance 8

Specifications 8

Warranty 9

WARRANTY REGISTRATION 11

WARNING: PLEASE ENSURE THAT ALL SAFETY INSTRUCTIONS ARE UNDERSTOOD BY ALL PERSONS WHO USE THIS APPLIANCE

Arabic

تحذير : تأكد من فهم كل من يستعمل الجهاز لكافة إحتياطات الأمان وتعليمات التشغيل .

Cambodian

ការព្រមានប្រាប់: សូមប្រាកដឲ្យបានច្បាស់ថាការប្រុងប្រយ័ត្នផ្នែកនិរភ័យ និងការប្រើប្រាស់ទាំងអស់ បានត្រូវកន្ទាស់ប្រាប់ច្បាស់លាស់ល្អ ទោះជាស្ថិតក្នុងការប្រើប្រាស់ឧបករណ៍ប្រភេទនេះហើយ ។

Chinese

警告：必需確保任何使用這器具的人士，已明瞭一切安全預防措施及操作指示。

Croatian

Upozorenje: Budite sigurni da svi koji rade na aparatima znaju o mjerama opreza i funkciji ovih aparata.

French

Attention: Veuillez vous assurer que toutes les personnes utilisant l'appareil comprennent tous les conseils d'utilisation et précautions de sécurité.

German

Warnung: Versichern Sie sich, daß alle Sicherheitsvorkehrungen und Bedienungsanleitungen von allen Benutzern des Gerätes verstanden worden sind.

Greek

Προειδοποίηση: Βεβαιωθήτε ότι όλα τα προφυλακτικά μέτρα ασφαλείας και οι οδηγίες λειτουργίας κατανοούνται από όλα τα άτομα που χρησιμοποιούν τη συσκευή.

Italian

Attenzione: assicuratevi che tutti coloro che adoperano i macchinari conoscano le misure di sicurezza e le istruzioni relative al funzionamento.

Macedonian

Предупредување: Осигурајте сите оние кои користат апарати ги разбираат мерките за безбедност и упатства за работа.

Malay

Amaran: Pastikan bahawa semua langkah keselamatan dan keterangan operasi telah difahami oleh semua pengguna alat ini.

Polish

Ostrzeżenie: upewnij się, że wszystkie środki ostrożności i instrukcje obsługi są rozumiane przez wszystkich używających tego urządzenia.

Portugese

Atenção: Assegure-se de que todas as medidas de segurança e instruções de funcionamento são compreendidas por todos aqueles que usam este aparelho.

Russian

Предупреждение: Позаботьтесь о том, чтобы все меры безопасности и инструкции по эксплуатации были поняты всеми, кто пользуется этим устройством.

Serbian

Упозорење: Водите рачуна да сви који употребљавају овај уређај знају мере предострожности и упутства за руковање.

Spanish

Advertencia: Haga que las precauciones e instrucciones para el uso de este aparato sean entendidas por todos los que lo usan.

Tagalog

Babala: Siguruhing ang lahat nu mga pangkaligtasang pag-iingat at mga tagubilin hinggil sa pagpapaandar ay naiintindihan ng lahat ng gumagamit ng kasangakapan.

Turkish

Uyarı: Tüm güvenlik önlemlerinin ve aygıtı çalıştırma talimatlarının aygıtı kullanan herkes tarafından anlaşılmış olmasını sağlayınız.

Vietnamese

Lưu ý: Chắc chắn rằng những người sử dụng máy đều đã hiểu rõ tất cả các chỉ dẫn về cách vận hành máy và các dự phòng an toàn.

RETAIN THESE SAFETY INSTRUCTIONS

General Safety Instructions for All Semak Products

- Do not use the appliance for other than its intended use.
- Never leave the appliance unattended when in use.
- The appliance should not be used by children or infirm persons and close supervision is necessary when used near such persons.
- Always switch off at power outlet before removing the plug. Remove by holding the plug – do not pull the cord.
- When the appliance is not in use, or prior to cleaning, always switch off the power and remove the plug.
- To avoid the risk of electric shock, do not immerse the plug, cord or any part of the appliance in water or any other liquid.
- Do not use near a stove or heat source and do not let the cord come in contact with any hot surface.
- Do not use the appliance with an extension cord unless that cord has been checked and tested by a qualified technician or if it is an extension cord that has been manufactured by a reliable electrical goods manufacturer and has not been altered in any way.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in anyway. Return to Semak or an authorised service agent for repair.
- CAUTION Hot Surfaces.
- NEVER leave the appliance ON unattended. ALWAYS unplug the cooker after use.

Safety Instructions

- Only use the appliance on a flat, level and stable surface. DO NOT use on a wet surface.
- When in operation the surfaces of the bun spiker and glass tank are EXTREMLY HOT
- DO NOT touch the Teflon coated bun spikes while the appliance is in operation.
- ALWAYS turn off the appliance and allow it to cool down before cleaning.
- The spikes remain hot for some time. Allow a minimum 15 minutes COOL DOWN to ensure that the bun spikes have cooled. NEVER pick up the bun spiker by the spikes to avoid burns of the hands, fingers, wrists.
- Use a barely damp cloth to wipe the bun spiker once it has cooled.
- DO NOT use running water when cleaning the bun spiker. Wipe the exterior with a damp cloth.
- DO NOT use caustic substances to clean the appliance and do not allow caustic substances to make contact with any electrical components of the warmer.

Operating Instructions for the Semak Hot Dog Cooker & Bun Spiker

- Locate the appliance on a level surface making sure that there is a clearance of 100mm around the appliance for ventilation.
- Make sure that the switches are in the “OFF” position. Plug into an earthed single phase 10Amp 240V AC power supply.
- Turn the switch for the corresponding tank or bun spikes on. The indicator switch will light up when “ON”. The “TANK” switch will turn the tank element on and the “SPIKES” switch will turn the spikes on
- Lift the lid, remove the wire rack and pour water into the tank to cover the element. Replace the tank and lid. Place hotdogs in the tank. Packing them tightly together increases the cook time required to heat them thoroughly.
- Turn the “TANK” switch to 2 or 3 so that the water will simmer. Allow the bun spiker to warm up 3-5 minutes. Adjust the temperature to achieve the desired level of heating.
- Check the water level in the tank each hour to ensure that there is sufficient water in the tank to cover the element. Top up if necessary.
- Ensure that the bun /roll is long enough to cover the whole spike. Short buns may have the end pierced by the spiker if they are not long enough and depending on how the hot dog etc is served this may cause sauce/mustard etc. to drip from the bun. Place the bun on the spike. DO NOT touch the spike with your hand to avoid burns. Some rolls/buns are soft and this can inadvertently lead to burns if the sides of the roll/bun collapse or are pierced. Extra care must be taken if using soft rolls and crispy ones are recommended.
- DO NOT butter the roll. Butter can be added after the roll is toasted.
- The buns are cooked when they appear toasted on the inside. Lift the bun off the spiker and look in to determine if it is toasted. As a guide they take 1-2 minutes. Add sauce if required and insert the hot dog.
- When finished heating turn the switches “Off”. The appliance is “OFF” when the indicator switches are no longer lit.

Cleaning Instructions for the Semak Hot Dog Cooker & Bun Spiker

- The Hot Dog Cooker must be cleaned daily as part of a HACCP Food Safety Program.
- ALWAYS turn off the appliance and allow it to cool down before cleaning.
- Remove the tank and lid and wash separately. Empty the tank.
- Pour a small amount of hot soapy water in the tank and wash greasy residues. Tip out soapy water and add clear water to rinse the soap away. Spray with a HACCP Endorsed food grade sanitizer and wipe dry.
- DO NOT leave water in the tank overnight
- The surface of the spiker is Teflon coated. Do not use abrasive materials on the spikes e.g. Steel wool or scourers etc as they will scratch the Teflon or accelerate the wear and tear of the Teflon, reducing the performance of the machine. If parts of the roll stick to the spikes remove with a damp cloth. A damp cloth is all that is necessary to clean the spikes
- Use a barely damp cloth to wipe the outside of the machine once it has cooled. DO NOT use running water to clean the appliance.
- DO NOT use caustic substances to clean the appliance and do not allow caustic substances to make contact with any electrical components of the appliance.
- It is important to note that Semak cannot warrant the Teflon coating of the spikes where damage is caused by using abrasive cleaning products or where scratching is caused by utensils. However, we do warrant the Teflon where it is evident that the materials are faulty or the workmanship is faulty.

Spare Parts for the Semak Hot Dog Cooker & Bun Spiker

Part Number	Description	Part Number	Description
19387	LABEL	38012	HEAT CONTROL w KNOB
86101	BUN SPIKE COMPLETE	86144	RUBBER FEET
86008	RED INDICATOR LIGHT	75210	LEAD & PLUG
86417	GLASS TANK	86416	LID COMPLETE
86408	WIRE RACK	86407	TANK ELEMENT

Spare Parts, exploded views and wiring diagrams are available from our webpage. Go to www.semak.com.au and locate the appliance in the product section for the above information.

Service & Maintenance

The Semak Hot Dog Cooker does not contain user-serviceable parts. For Service and Repair, contact Semak for your nearest Authorised Service Agent

The Foodservice Industry is deemed a hostile environment within the scope of AS/NZS 3760:2003. Semak Hot Dog Cooker and Bun Warmer MUST be routinely electrically tested for compliance with this standard if used commercially.

It is recommended that a Food Safety program such as HACCP be employed and that routine service and repair be undertaken at the time of electrical testing to ensure the correct operation and function of all parts.

Electrical Compliance

Semak Hot Dog Cooker & Bun Warmers comply with the following electrical standards

CISPR 14

Specifications

Model	**HD3T**
Dimensions	350 x 320 x 300mm
Volts	240AC 10AMP
Electrical	970W

Warranty

The Semak Hot Dog Cooker and Bun Warmer is a Commercial appliance. This product is guaranteed for 2 Years* from the date of purchase against mechanical and electrical defects. If the fault is deemed caused by MISUSE/ABUSE the terms of the warranty are invalidated. If the product has been opened or tampered with (i.e. In an attempt to repair it) the warranty is invalidated. All warranty repairs should be undertaken by Semak Australia.

It is against company policy to authorize warranty repairs over the phone. Service Agents will require a work order number from Semak to conduct warranty repairs.

*Warranty excludes, Elements and Teflon Coating

SEMAK® WARRANTY

THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED AND SOLD IN AUSTRALIA

The benefits conferred by this warranty are an alternative to all other rights and remedies in respect of the product which the consumer has under the Trade Practices Act and similar State and Territory Laws.

Semak Australia. Warrant each new SEMAK appliance manufactured by SEMAK to be free from defects in materials or manufacturing process for a period of 2 years from the date of original purchase.

Should defects due to faulty materials or manufacturing process develop within the warranty period, the appliance will be repaired without charge providing all conditions of this warranty are observed.

1. Proof of Purchase and Warranty card must be retained and available on request.
2. This Warranty is void if the equipment has been damaged due to misuses neglect or is used for a purpose for which it was not suited; and no repairs, alterations or modifications have been attempted by other than Semak or its authorised Service Agent.
3. Semak Australia. Reserves the right to reject a claim for warranty if service is required due to misapplication, improper installation, inadequate wiring, and incorrect voltage conditions. Under no circumstances shall SEMAK or its agents bear responsibility for consequential damages of any kind.
4. Where required by Statute or local authority, equipment must be installed by qualified person in accordance with all relevant regulations. Failure to do this will void product warranty.
5. Cost of transport of any appliance or part to and from SEMAK or its Service Agent is to be paid by the owner.
6. A charge will be made where failure is due to neglect, abuse or accidental damage on the part of the operator, or when no fault can be found or the fault is due to causes outside the control of Semak Australia.
7. The above does not preclude the purchaser from their Statutory rights as a consumer.

Semak Australia
Factory 18
87-91 Hallam South Road
HALLAM VIC 3803
Ph 61 3 9796 4583
Fax 613 9796 4586
Email technical@semak.com.au

WARRANTY REGISTRATION

Retain for Future Reference

DO NOT SEND

Please complete one registration for each Semak appliance.

You may be required to provide this information when requesting after sales service. Please staple your proof of purchase to this page.

Company Name: _____

Company Address: _____

Business Type: _____

Contact: _____

Phone: _____

Fax: _____

Email: _____

Product: _____

Serial Number: _____

Date of Purchase: _____

Place of Purchase: _____

© 2011 Semak Australia