SEMAK

SEMAK HOT WATER URNS

OPERATION AND WARRANTY BOOKLET

SEMAK AUSTRALIA: FACTORY 18, 87-91 HALLAM SOUTH ROAD, HALLAM VIC 3803

PH 03 9796 4583 FAX 03 9796 4586 WEB WWW.SEMAK.COM.AU

Table of Contents

General Safety Instructions for All Semak Products 4

Safety Instructions 5

Operating Instructions for the Semak Hot Water Urn 5

Cleaning Instructions for the Semak Hot Water Urn 6

Spare Parts for the Semak Hot Water Urn 6

Service & Maintenance 6

Spare Parts 7

Electrical Compliance 7

Warranty 7

WARRANTY REGISTRATION 9

WARNING: PLEASE ENSURE THAT ALL SAFETY INSTRUCTIONS ARE UNDERSTOOD BY ALL PERSONS WHO USE THIS APPLIANCE

Arabic

تحـذيـر : تأكد من فهم كل من يستعمل الجهاز لكـافة إحتيـاطات الأمـان وتعلـيمات التشغيـل .

Cambodian

ការព្រមានប្រាប់: សូមប្រាកដឲ្យបានច្បាស់ថាការប្រុងប្រយ័ត្នវ៉ែនតានិរភ័យ និងការណែនាំប្រើទាំងអស់ បានត្រូវកន្ទ្ទាស់ប្រាប់ច្បាស់លាស់ល្អ ទោះជាសំរាប់អ្នកដែលប្រើប្រាស់ក្រឿងប្រដាប់ទាំងនេះហើយ ។

Chinese

警告：必需確保任何使用這器具的人士，已明瞭一切安全預防措施及操作指示。

Croatian

Upozorenje: Budite sigurni da svi koji rade na aparatima znaju o mjerama opreza i funkciji ovih aparata.

French

Attention: Veuillez vous assurer que toutes les personnes utilisant l'appareil comprennent tous les conseils d'utilisation et précautions de sécurité.

German

Warnung: Versichern Sie sich, daß alle Sicherheitsvorkehrungen und Bedienungsanleitungen von allen Benutzern des Gerätes verstanden worden sind.

Greek

Προειδοποίηση: Βεβαιωθήτε ότι όλα τα προφυλακτικά μέτρα ασφαλείας και οι οδηγίες λειτουργίας κατανοούνται από όλα τα άτομα που χρησιμοποιούν τη συσκευή.

Italian

Attenzione: assicuratevi che tutti coloro che adoperano i macchinari conoscano le misure di sicurezza e le istruzioni relative al funzionamento.

Macedonian

Предупредување: Осигурајте сите оние кои користат апарати ги разбираат мерките за безбедност и упатства за работа.

Malay

Amaran: Pastikan bahawa semua langkah keselamatan dan keterangan operasi telah difahami oleh semua pengguna alat ini.

Polish

Ostrzeżenie: upewnij się, że wszystkie środki ostrożności i instrukcje obsługi są rozumiane przez wszystkich używających tego urządzenia.

Portugese

Atenção: Assegure-se de que todas as medidas de segurança e instruções de funcionamento são compreendidas por todos aqueles que usam este aparelho.

Russian

Предупреждение: Позаботьтесь о том, чтобы все меры безопасности и инструкции по эксплуатации были поняты всеми, кто пользуется этим устройством.

Serbian

Упозорење: Водите рачуна да сви који употребљаааају овај уређај знају мере предострожности и упутства за руковање.

Spanish

Advertencia: Haga que las precauciones e instrucciones para el uso de este aparato sean entendidas por todos los que lo usan.

Tagalog

Babala: Siguruhing ang lahat nu mga pangkaligtasang pag-iingat at mga tagubilin hinggil sa pagpapaandar ay naiintindihan ng lahat ng gumagamit ng kasangakapan.

Turkish

Uyarı: Tüm güvenlik önlemlerinin ve aygıtı çalıştırma talimatlarının aygıtı kullanan herkes tarafından anlaşılmış olmasını sağlayınız.

Vietnamese

Lưu ý: Chắc chắn rằng những người sử dụng máy đều đã hiểu rõ tất cả các chỉ dẫn về cách vận hành máy và các dự phòng an toàn.

RETAIN THESE SAFETY INSTRUCTIONS

General Safety Instructions for All Semak Products

- Do not use the appliance for other than its intended use.
- Never leave the appliance unattended when in use.
- The appliance should not be used by children or infirm persons and close supervision is necessary when used near such persons.
- Always switch off at power outlet before removing the plug. Remove by holding the plug – do not pull the cord.
- When the appliance is not in use, or prior to cleaning, always switch off the power and remove the plug.
- To avoid the risk of electric shock, do not immerse the plug, cord or any part of the appliance in water or any other liquid.
- Do not use near a stove or heat source and do not let the cord come in contact with any hot surface.
- Do not use the appliance with an extension cord unless that cord has been checked and tested by a qualified technician or if it is an extension cord that has been manufactured by a reliable electrical goods manufacturer and has not been altered in any way.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in anyway. Return to Semak or an authorised service agent for repair.
- CAUTION Hot Surfaces.
- NEVER leave the appliance ON unattended. ALWAYS unplug the Hot Water Urn after use.

Safety Instructions

- Only use the appliance on a flat, level and stable surface. DO NOT use on a wet surface.
- When in operation the surfaces of the urn are HOT.
- The contents of the urn are very HOT. Be careful not to splatter the contents when pouring to avoid burns. Steam will be expired when the lid is lifted and care needs to be taken that the lid is lifted in a way to avoid steam burns of the wrists and hands.
- DO NOT touch the heating element while the machine is in operation.
- ALWAYS turn off the appliance and allow it to cool down before cleaning.
- Use a barely damp cloth to wipe the machine once it has cooled.
- DO NOT use caustic substances to clean the warmer and do not allow caustic substances to make contact with any electrical components of the warmer.

WARNING – This appliance should be used according to the instructions.

MISUSE of this appliance will cause HAZARD.

Operating Instructions for the Semak Hot Water Urn

1. Make sure that the knob is in the "OFF" position.
2. Plug into an earthed 240V AC power supply.
3. Fill the vessel with water to the desired level using the water level indicator as a guide.
4. Turn the switch knob on the urn until the dial reaches 'MAX' for maximum heat and allow the water to boil.
5. To keep the water at a simmering boiling temperature, turn the knob back until the pilot light goes off, this will allow the urn to cycle on and off maintaining water at slightly below boiling point.
6. When the urn requires additional water, add the water and turn the knob to 'MAX' and allow the contents to boil.
7. The urn has boil dry protection, however ensure that the urn is turned off when NOT in use.
8. DO NOT run the urn when empty. The heating time will vary depending on the volume of water within.
9. When finished heating turn the knob to the "Off" position.
10. Clean the appliance with a damp cloth.
11. NEVER leave the warmer on unattended. ALWAYS unplug the Urn after use.

Cleaning Instructions for the Semak Hot Water Urn

1. ALWAYS turn off the appliance and allow it to cool down before cleaning.
2. Use a barely damp cloth to wipe the machine once it has cooled.
3. To clean the inside surface of mineral build up, use 1 tablespoon full of Urn Cleaner to a full container of cold water, then boil the contents and wait until the deposits have been dissolved. Empty contents, rinse and fill with fresh cold water, boil and use.
4. DO NOT hose out the inside of machine. Wipe the interior with a damp cloth.
5. DO NOT use caustic substances to clean the warmer and do not allow caustic substances to make contact with any electrical components of the warmer.

Spare Parts for the Semak Hot Water Urn

Part Number	Description	Part Number	Description
85001	Tap Assembly	85012	Level Tube 20 Lt
85002	Element simmerstat type	85013	Level Tube 30 Lt
85003	Simmerstat control	85014	Level Tube 40 Lt
85004	Simmerstat knob	85015	Lid Assembly 10 Lt
85005	Indicator Red light	85016	Lid Assembly 20 Lt
85006	Cord & Plug Assembly	85017	Lid Assembly 30 & 40 Lt
85007	Side Handle (20 30 40 Lt)	85022	Urn Cleaner
85008	Side Handle 10 Lt	85024	Thermostat knob 30-110 Deg
85009	Lid knob grained	85025	Thermostat
85010	Elbow (Level indicator)	85026	Element suit 10 Lt type
85011	Level Tube 10 Lt	85032	Element thermostat type

Service & Maintenance

The Semak Hot Water Urn does not contain user-serviceable parts. For Service and Repair, contact Semak for your nearest Authorised Service Agent.

The Foodservice Industry is deemed a hostile environment within the scope of AS/NZS 3760:2003. Semak Hot Water Urn MUST be routinely electrically tested for compliance with this standard if used commercially.

It is recommended that a Food Safety program such as HACCP be employed and that routine service and repair be undertaken at the time of electrical testing to ensure the correct operation and function of all parts.

Spare Parts

Spare Parts, exploded views and wiring diagrams are available from our webpage. Go to www.semak.com.au and locate the appliance in the product section for the above information.

Electrical Compliance

Semak Hot Water Urns comply with the following electrical standards

CISPR 14

Warranty

The Semak Hot Water Urn is a Commercial appliance. This product is guaranteed for 1 Year from the date of purchase against mechanical and electrical defects. If the fault is deemed caused by MISUSE/ABUSE the terms of the warranty are invalidated. If the product has been opened or tampered with (ie. In an attempt to repair it) the warranty is invalidated. All warranty repairs should be undertaken by Semak.

It is against company policy to authorize warranty repairs over the phone. Service Agents will require a work order number from Semak to conduct warranty repairs.

SEMAK® WARRANTY

THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED AND SOLD IN AUSTRALIA

The benefits conferred by this warranty are an alternative to all other rights and remedies in respect of the product which the consumer has under the Trade Practices Act and similar State and Territory Laws.

Semak Australia. Warrant each new SEMAK appliance manufactured by SEMAK to be free from defects in materials or manufacturing process for a period of 1 Year from the date of original purchase.

Should defects due to faulty materials or manufacturing process develop within the warranty period, the appliance will be repaired without charge providing all conditions of this warranty are observed.

1. Proof of Purchase and Warranty card must be retained and available on request.
2. This Warranty is void if the equipment has been damaged due to misuses neglect or is used for a purpose for which it was not suited; and no repairs, alterations or modifications have been attempted by other than Semak or its authorised Service Agent.
3. Semak Australia. Reserves the right to reject a claim for warranty if service is required due to misapplication, improper installation, inadequate wiring, and incorrect voltage conditions. Under no circumstances shall SEMAK or its agents bear responsibility for consequential damages of any kind.
4. Where required by Statute or local authority, equipment must be installed by qualified person in accordance with all relevant regulations. Failure to do this will void product warranty.
5. Cost of transport of any appliance or part to and from SEMAK or its Service Agent is to be paid by the owner.
6. A charge will be made where failure is due to neglect, abuse or accidental damage on the part of the operator, or when no fault can be found or the fault is due to causes outside the control of Semak Australia.
7. The above does not preclude the purchaser from their Statutory rights as a consumer.

Semak Australia
Factory 18
87-91 Hallam South Road
HALLAM VIC 3803

Ph 03 9796 4583
Fax 03 9796 4586
Email technical@semak.com.au
Web www.semak.com.au

WARRANTY REGISTRATION

Retain for Future Reference

DO NOT SEND

Please complete one registration for each Semak appliance.

You may be required to provide this information when requesting after sales service. Please staple your proof of purchase to this page.

Company Name: _____

Company Address: _____

Business Type: _____

Contact: _____

Phone: _____

Fax: _____

Email: _____

Product: _____

Serial Number: _____

Date of Purchase: _____

Place of Purchase: _____

Notes

© Semak 2018