SEMAK

SEMAK VITASHAKE® MILKSHAKE MIXER
MODELS VSR, VSB & VSS

OPERATION AND WARRANTY BOOKLET

VSR

VSB

VSS

SEMAK AUSTRALIA - FACTORY 18, 87-91 HALLAM SOUTH ROAD, HALLAM VIC 3803

PH: 03 9796 4583 FAX: 03 9796 4586 WEB: WWW.SEMAK.COM.AU

Table of Contents

IMPORTANT SAFETY INSTRUCTIONS 4

OPERATING INSTRUCTIONS: VSR, VSB & BSS 5

CLEANING & MAINTENANCE INSTRUCTIONS 5

SERVICE & MAINTENANCE 6

SPARE PARTS 6

WARRANTY 6

WARRANTY REGISTRATION 8

WARNING: PLEASE ENSURE THAT ALL SAFETY INSTRUCTIONS ARE UNDERSTOOD BY ALL PERSONS WHO USE THIS APPLIANCE

Arabic

تحـذيـر : تأكد من فهم كل من يستعمل الجهاز لكـافة إحتيـاطات الأمـان وتعليمات التشغيـل .

Cambodian

ការព្រមានប្រាប់: សូមប្រាកដឲ្យបានច្បាស់ថាការប្រុងប្រយ័ត្នផ្នែកនិរភ័យ និងការណែនាំទាំងអស់ បានត្រូវកន្ទាស់ប្រាប់ច្បាស់លាស់ល្អ ទោះជាអ្នកដែលប្រើប្រាស់ម៉ាស៊ីនេះហើយ ។

Chinese

警告：必需確保任何使用這器具的人士，已明瞭一切安全預防措施及操作指示。

Croatian

Upozorenje: Budite sigurni da svi koji rade na aparatima znaju o mjerama opreza i funkciji ovih aparata.

French

Attention: Veuillez vous assurer que toutes les personnes utilisant l'appareil comprennent tous les conseils d'utilisation et précautions de sécurité.

German

Warnung: Versichern Sie sich, daß alle Sicherheitsvorkehrungen und Bedienungsanleitungen von allen Benutzern des Gerätes verstanden worden sind.

Greek

Προειδοποίηση: Βεβαιωθήτε ότι όλα τα προφυλακτικά μέτρα ασφαλείας και οι οδηγίες λειτουργίας κατανοούνται από όλα τα άτομα που χρησιμοποιούν τη συσκευή.

Italian

Attenzione: assicuratevi che tutti coloro che adoperano i macchinari conoscano le misure di sicurezza e le istruzioni relative al funzionamento.

Macedonian

Предупредување: Осигурајте сите оние кои користат апарати ги разбираат мерките за безбедност и упатства за работа.

Malay

Amaran: Pastikan bahawa semua langkah keselamatan dan keterangan operasi telah difahami oleh semua pengguna alat ini.

Polish

Ostrzeżenie: upewnij się, że wszystkie środki ostrożności i instrukcje obsługi są rozumiane przez wszystkich używających tego urządzenia.

Portugese

Atenção: Assegure-se de que todas as medidas de segurança e instruções de funcionamento são compreendidas por todos aqueles que usam este aparelho.

Russian

Предупреждение: Позаботьтесь о том, чтобы все меры безопасности и инструкции по эксплуатации были поняты всеми, кто пользуется этим устройством.

Serbian

Упозорење: Водите рачуна да сви који употребљавају овај уређај знају мере предострожности и упутства за руковање.

Spanish

Advertencia: Haga que las precauciones e instrucciones para el uso de este aparato sean entendidas por todos los que lo usan.

Tagalog

Babala: Siguruhing ang lahat nu mga pangkaligtasang pag-iingat at mga tagubilin hinggil sa pagpapaandar ay naiintindihan ng lahat ng gumagamit ng kasangakapan.

Turkish

Uyarı: Tüm güvenlik önlemlerinin ve aygıtı çalıştırma talimatlarının aygıtı kullanan herkes tarafından anlaşılmış olmasını sağlayınız.

Vietnamese

Lưu ý: Chắc chắn rằng những người sử dụng máy đều đã hiểu rõ tất cả các chỉ dẫn về cách vận hành máy và các dự phòng an toàn.

RETAIN THESE SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

Please read all of the instructions before using the Vitashake Milkshake Mixer and ensure that other operators read and understand safety & operating instructions. Save these instructions for Future reference. Thank you for purchasing a Vitashake Milkshake Mixer.

1. Ensure that power supply is switched off before connecting to the electric outlet.
2. Use only on AC 240V – 50 Hz only without an extension cord.
3. To avoid risk of electric shock, do not immerse cord, plug or motor end of the appliance in water or any other liquid. Never put the Vitashake in a dishwasher.
4. Always switch off at the power outlet before removing the plug. Remove by holding the plug - do not pull on the cord. When the appliance is not in use, or prior to cleaning, always switch off the power and remove the plug.
5. Disconnect the power cord from the electrical outlet when the mixer is not in use.
6. The Vitashake should not be used by children or infirm persons and care should be taken when used near these persons. The Vitashake should not be used outdoors. Young children should be supervised to ensure that they do not play with the appliance. Never leave the mixer unattended.
7. Avoid physical contact with moving parts. The mixing blades are very sharp and **care is needed when handling mixing blades**, and only when the Vitashake is disconnected from the power supply. Never attempt to touch the mixing blades when mixer is in use.
8. Never operate the Vitashake without the container securely in place. Never operate the Vitashake with an empty container.
9. Do not use on the stove or let the cord come into contact with any hot surface.
10. Keep hands and utensils out of the container while using the Vitashake to prevent the possibility of severe injury to persons or damage to the unit.
11. WARNING: Blade is sharp. Please handle carefully
    - DO NOT try to remove blade while the motor base is connected to power.
    - DO NOT operate with loose, nicked or damaged blade, replace immediately.
    - CAUTION keep all utensils AWAY FROM the motor shaft and mixer blades during operation. Metal utensils will damage blades.
    - DO NOT locate container into container bracket if mixer motor is operating.
    - DO NOT rock the mixer during operation.
    - DO NOT mix hot liquids. Intended only for cold liquids.
12. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, is dropped or damaged in any way. Return the appliance to Semak or one of its Authorised Service Agent for repair. **Do not attempt to repair the machine.**
13. For Safety reasons and to avoid maintenance by unskilled persons, the appliance should always be returned to Semak for adjustment or repair if required.

OPERATING INSTRUCTIONS: VSR, VSB & VSS

The Semak Vitashake mixes quickly and efficiently.
Use it to make milkshakes, thickshakes, frappes and cocktails.

1. Before connecting to electrical outlet, wash the container and its parts and also, wipe the mixer base with a damp cloth.
2. Ensure that the power supply is also switched off before connecting to the electrical outlet. Turn the power ON.
3. Place ingredients in the container.
4. Place container into position on the spindle bracket.
5. Turn the mixer ON at the switch found on the head of the machine.
6. When ingredients are mixed, turn the mixer OFF.
7. Do not leave mixer unattended or leave contents in the container when not in use.

CLEANING & MAINTENANCE INSTRUCTIONS

Always unplug the Vitashake mixer from the power source before cleaning. Wash the container and other stainless steel parts with a HACCP detergent. The unit is easiest to clean immediately after completing the mixing task.

- A HACCAP sanitizer may be used to minimize bacterial contamination.
- Clean appliance by wiping with a barely damp cloth only.
- **Never** immerse the motor, plug or cord in water or any other liquid.

SERVICE & MAINTENANCE

For Service and Repair, contact Semak for your nearest Authorised Service Agent

The Foodservice Industry is deemed a hostile environment within the scope of AS/NZS 3760:2003. Semak Vitashake MUST be routinely electrically tested for compliance with this standard if used commercially.

It is recommended that a Food Safety program such as HACCP be employed and that routine service and repair be undertaken at the time of electrical testing to ensure the correct operation and function of all parts. The equipment MUST be serviced annually or sooner depending of the hostility of the environment in which it is operated.

SPARE PARTS

Spare Parts, exploded views and wiring diagrams are available from our webpage. Go to www.semak.com.au and locate the appliance in the product section for the above information.

WARRANTY

Model VSR, VSB & VSS is a Commercial Grade milkshake maker suitable for commercial use. This product is guaranteed for 2 years (lifetime motor warranty) from the date of purchase against mechanical and electrical defects.

If the fault is deemed caused by MISUSE/ABUSE the terms of the warranty are invalidated. If the product has been opened or tampered with (ie. In an attempt to repair it) the warranty is invalidated. All warranty repairs should be undertaken by Semak Australia.

It is against company policy to authorize warranty repairs over the phone. Service Agents will require a work order number from Semak to conduct warranty repairs.

SEMAK® WARRANTY

THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED AND SOLD IN AUSTRALIA

The benefits conferred by this warranty are an alternative to all other rights and remedies in respect of the product which the consumer has under the Trade Practices Act and similar State and Territory Laws.

Semak Australia. Warrant each new SEMAK appliance manufactured by SEMAK to be free from defects in materials or manufacturing process for a period of 2 years (lifetime on motor) from the date of original purchase.

Should defects due to faulty materials or manufacturing process develop within the warranty period, the appliance will be repaired without charge providing all conditions of this warranty are observed.

1. Proof of Purchase and Warranty card must be retained and available on request.
2. This Warranty is void if the equipment has been damaged due to misuses neglect or is used for a purpose for which it was not suited; and no repairs, alterations or modifications have been attempted by other than Semak or its authorised Service Agent.
3. Semak Australia. Reserves the right to reject a claim for warranty if service is required due to misapplication, improper installation, inadequate wiring, and incorrect voltage conditions. Under no circumstances shall SEMAK or its agents bear responsibility for consequential damages of any kind.
4. Where required by Statute or local authority, equipment must be installed by qualified person in accordance with all relevant regulations. Failure to do this will void product warranty.
5. Cost of transport of any appliance or part to and from SEMAK or its Service Agent is to be paid by the owner.
6. A charge will be made where failure is due to neglect, abuse or accidental damage on the part of the operator, or when no fault can be found or the fault is due to causes outside the control of Semak Australia.
7. The above does not preclude the purchaser from their Statutory rights as a consumer.

Semak Australia
Factory 18, 87-91 Hallam South Road
HALLAM VIC 3803

Ph 03 9796 4583
Fax 03 9796 4586
Email technical@semak.com.au

WARRANTY REGISTRATION

Retain for Future Reference

DO NOT SEND

Please complete one registration for each Semak appliance.

You may be required to provide this information when requesting after sales service. Please staple your proof of purchase to this page.

Company Name: _____

Company Address: _____

Business Type: _____

Contact: _____

Phone: _____

Fax: _____

Email: _____

Product: _____

Serial Number: _____

Date of Purchase: _____

Place of Purchase: _____

© Semak Australia 2016