SEMAK

BS3 HOT DOG BUN SPIKER

INSTALLATION, OPERATION AND WARRANTY BOOKLET

BS3

SEMAK AUSTRALIA: FACTORY 18, 87-91 HALLAM SOUTH ROAD, HALLAM VIC 3803

PH 03 9796 4583 FAX 03 9796 4586 WEB WWW.SEMAK.COM.AU

Table of Contents

Safety Instructions 3

Safety Instructions cont. 4

Operating Instructions 5

Cleaning Instructions 6

Service and Repair 7

Service and Repair Procedure 7

Semak Warranty 8

Warranty Registration 9

Notes 10

Notes 11

Safety Instructions

WARNING: PLEASE ENSURE THAT ALL SAFETY INSTRUCTIONS ARE UNDERSTOOD BY ALL PERSONS WHO USE THIS APPLIANCE

Arabic

تحـذيـر : تأكد من فهم كل من يستعمل الجهاز لكـافة إحتيـاطات الأمـان وتعليمات التشغيـل .

Cambodian

ការព្រមានត្រាប់: សូមត្រួតពិនិត្យឲ្យបានច្បាស់ថាការប្រុងប្រយ័ត្នផ្នែកទិដ្ឋភាពសុវត្ថិភាព និងការណែនាំប្រើប្រាស់ទាំងអស់ បានត្រូវការយល់ត្រាប់ច្បាស់លាស់ល្អ ទោះជាអ្នកដែលប្រើប្រាស់ម៉ាស៊ីនប្រភេទនេះហើយ ។

Chinese

警告：必需確保任何使用這器具的人士，已明瞭一切安全預防措施及操作指示。

Croatian

Upozorenje: Budite sigurni da svi koji rade na aparatima znaju o mjerama opreza i funkciji ovih aparata.

French

Attention: Veuillez vous assurer que toutes les personnes utilisant l'appareil comprennent tous les conseils d'utilisation et précautions de sécurité.

German

Warnung: Versichern Sie sich, daß alle Sicherheitsvorkehrungen und Bedienungsanleitungen von allen Benutzern des Gerätes verstanden worden sind.

Greek

Προειδοποίηση: Βεβαιωθήτε ότι όλα τα προφυλακτικά μέτρα ασφαλείας και οι οδηγίες λειτουργίας κατανοούνται από όλα τα άτομα που χρησιμοποιούν τη συσκευή.

Italian

Attenzione: assicuratevi che tutti coloro che adoperano i macchinari conoscano le misure di sicurezza e le istruzioni relative al funzionamento.

Macedonian

Предупредување: Осигурајте сите оние кои користат апарати ги разбираат мерките за безбедност и упатства за работа.

Malay

Amaran: Pastikan bahawa semua langkah keselamatan dan keterangan operasi telah difahami oleh semua pengguna alat ini.

Polish

Ostrzeżenie: upewnij się, że wszystkie środki ostrożności i instrukcje obsługi są rozumiane przez wszystkich używających tego urządzenia.

Portugese

Atenção: Assegure-se de que todas as medidas de segurança e instruções de funcionamento são compreendidas por todos aqueles que usam este aparelho.

Russian

Предупреждение: Позаботьтесь о том, чтобы все меры безопасности и инструкции по эксплуатации были поняты всеми, кто пользуется этим устройством.

Serbian

Упозорење: Водите рачуна да сви који употребљаваају овај уређај знају мере предострожности и упутства за руковање.

Spanish

Advertencia: Haga que las precauciones e instrucciones para el uso de este aparato sean entendidas por todos los que lo usan.

Tagalog

Babala: Siguruhing ang lahat nu mga pangkaligtasang pag-iingat at mga tagubilin hinggil sa pagpapaandar ay naiintindihan ng lahat ng gumagamit ng kasangakapan.

Turkish

Uyarı: Tüm güvenlik önlemlerinin ve aygıtı çalıştırma talimatlarının aygıtı kullanan herkes tarafından anlaşılmış olmasını sağlayınız.

Vietnamese

Lưu ý: Chắc chắn rằng những người sử dụng máy đều đã hiểu rõ tất cả các chỉ dẫn về cách vận hành máy và các dự phòng an toàn.

Safety Instructions cont.

1. Do not use the appliance for other than its intended use.
2. Never leave the appliance unattended when in use.
3. The appliance should not be used by children or infirm persons and close supervision is necessary when used near such persons.
4. Always switch off at power outlet before removing the plug. Remove by holding the plug – do not pull the cord.
5. When the appliance is not in use or prior to cleaning, always switch off power and remove the plug.
6. To avoid the risk of electric shock, do not immerse the plug, cord or any part of the appliance in water or any other liquid.
7. Do not use near a stove or heat source and do not let the cord come in contact with any hot surface.
8. Do not use the appliance with an extension cord unless that cord has been checked and tested by a qualified technician or if it is an extension cord that has been manufactured by a reliable electrical goods manufacturer and has not been altered in any way.
9. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any way. Return to Semak or an authorised service agent.
10. CAUTION Hot Surfaces.
11. NEVER leave the appliance ON unattended. ALWAYS unplug the Hot Dog Spiker after use.
12. Only use the appliance on a flat, level and stable surface.
13. DO NOT use on a wet surface.
14. When in operation the surfaces of the bun spiker are EXTREMLY HOT.
15. DO NOT touch the Bun Spikes while the appliance is in operation.
16. ALWAYS turn off the appliance and allow it to cool down before cleaning.
17. The spikes remain hot for some time. Allow a minimum 15 minutes COOL DOWN to ensure that the bun spikes have cooled. NEVER pick up the bun spiker by the spikes to avoid burns of the hands, fingers, wrists.
18. Use a barely damp cloth to wipe the bun spiker once it has cooled.
19. DO NOT use running water when cleaning the Bun Spiker. Wipe the exterior with a lightly damp cloth only.
20. DO NOT use caustic substances to clean the appliance and do not allow caustic substances to make contact with any electrical components of the warmer.

ENSURE THAT THE ABOVE SAFETY INSTRUCTIONS ARE UNDERSTOOD BY ALL PERSONS WHO USE THE APPLIANCE.

Operating Instructions

1. Make sure that the switches are in the “OFF” position.

2. Plug into an earthed 220-240V AC power supply.

3. Turn the switch for the corresponding bun spikes on. The indicator switch will light up when “ON”. The “FRONT” switch will turn the front three (3) spikes on and the “REAR” (N.B BS6 only) switch will turn the rear (3) spikes on.

4. Allow the bun spiker to warm up for 3-5 minutes.

5. Ensure that the bun/roll is long enough to cover the whole spike. Short buns may have the end pierced by the spiker if they are not long enough and depending on how the hot dog etc is served this may cause sauce/mustard etc. to drip from the bun. Place the bun on the spike. DO NOT touch the spike with your hand to avoid burns. Some rolls/buns are soft and this can inadvertently lead to burns if the sides of the roll/bun collapse or are pierced. Extra care must be taken if using soft rolls and crispy ones are recommended.

6. DO NOT butter the roll. Butter can be added after the roll is toasted.

7. The buns are cooked when they appear toasted on the inside. Lift the bun off the spiker and look in to determine if it is toasted. As a guide they take 1-2 minutes.

8. When finished heating turn the switch “OFF”. The spikes are “OFF” when the indicator switch is no longer lit.

9. Clean the appliance with a damp cloth.

10. NEVER leave the Bun Spiker ON unattended.

11. ALWAYS unplug the warmer after use.

Cleaning Instructions

Semak Bun Spikers should be cleaned on a regular basis for optimal operation.

To clean the machine:

1. ALWAYS turn off the appliance and allow it to cool down before cleaning.
2. Use a barely damp cloth to wipe the machine once it has cooled.
3. DO NOT use running water to clean the appliance.
4. DO NOT use caustic substances to clean the appliance and do not allow caustic substances to make contact with any electrical components of the appliance.
5. Do not use abrasive materials on the spikes e.g. Steel wool or scourers etc as they will scratch the Teflon (if applicable) reducing the performance of the machine. If parts of the roll stick to the spikes remove with a damp cloth.

Spare Parts for the Semak Bun Spiker

Part Number	Description	Part Number	Description
19387	LABEL	38012	HEAT CONTROL WITH KNOB
86101	BUN SPIKE COMPLETE	86144	RUBBER FEET
86008	RED INDICATOR LIGHT	75210	LEAD & PLUG

Spare Parts, exploded views and wiring diagrams are available from our webpage. Go to www.semak.com.au and locate the appliance in the product section for the above information.

Service and Repair

In the event of breakdown attempt to solve the problem by working through the troubleshooting and FAQ sections of the Instruction manual.

If the problem cannot be identified or fixed, go to www.semak.com.au to make a service request. A response will be sent by email and will include instructions on where to take or send the unit to.

Semak use Authorised Service Agents. No claims will be recognised by Semak if an unauthorised repairer attends the machine.

Warranty claims are subject to Semak's discretion, and all warranty work is to be undertaken by Semak authorised service agents. No claims for warranty will be recognised unless accompanied by a Semak work order number. It is against company policy to provide verbal confirmation or authorization for warranty repair over the phone.

Service and Repair Procedure

1. Attempt to identify the problem

2. Book a Service Request at www.semak.com.au

3. When booking a service request, complete:

- Name
- Email Address
- Postal Address
- Model Number
- Date of purchase
- Serial Number

4. Follow emailed instructions

SEMAK WARRANTY

THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED AND SOLD IN AUSTRALIA

The benefits conferred by this warranty are an alternative to all other rights and remedies in respect of the product which the consumer has under the Trade Practices Act and similar State and Territory Laws.

Semak warrant each new appliance to be free from defects in materials or manufacturing process for a period of 2 years from the date of original purchase.

Should defects due to faulty materials or manufacturing process develop within the warranty period, the appliance will be repaired without charge providing all conditions of this warranty are observed.

1. Proof of Purchase must be retained by the purchaser.

2. This Warranty is void if the equipment has been damaged due to misuses neglect or is used for a purpose for which it was not suited; and no repairs, alterations or modifications have been attempted by other than Semak or its authorised Service Agent.

3. Semak is not responsible for service required due to misapplication, improper installation, inadequate wiring, incorrect voltage conditions, nor for consequential damages of any kind. Where required by Statute or local authority, equipment must be installed by qualified person in accordance with all relevant regulations.

4. Cost of transport of any appliance or part to and from Semak or its Service Agent is to be paid by the owner.

5. A charge will be made where failure is due to neglect, abuse or accidental damage on the part of the operator, or when no fault can be found or the fault is due to causes outside the control of Semak.

6. The above does not preclude the purchaser from their Statutory rights as a consumer.

Register Warranty Online at

www.semak.com.au

Semak Australia
Factory 18
87-91 Hallam South Road
HALLAM VIC 3803

Ph 03 9796 4583
Fax 03 9796 4586
Email technical@semak.com.au
Web www.semak.com.au

Warranty Registration

Retain for Future Reference

DO NOT SEND

Please complete one registration for each Semak appliance.

You may be required to provide this information when requesting after sales service. Please staple your proof of purchase to this page.

Company Name: _____

Company Address: _____

Business Type: _____

Contact: _____

Phone: _____

Fax: _____

Email: _____

Product: _____

Serial Number: _____

Date of Purchase: _____

Place of Purchase: _____

Notes

Notes

© 2017 Semak Australia