

# SEMAK

SEMAK VITACRUSH BAR BLENDERS  
MODELS VCE1500B, VCM1390R & VCE1050B

## OPERATION AND WARRANTY BOOKLET



VCM1390R



VCE1050B



VCE1500B

SEMAK AUSTRALIA: FACTORY 18, 87-91 HALLAM SOUTH ROAD, HALLAM VIC 3803

PH 03 9796 4583

FAX 03 9796 4586

WEB [WWW.SEMAK.COM.AU](http://WWW.SEMAK.COM.AU)

## **Table of Contents**

IMPORTANT SAFETY INSTRUCTIONS.....	4
BLENDER MODELS .....	6
OPERATING INSTRUCTIONS: VCE1500B & VCE1050B .....	7
OPERATING INSTRUCTIONS: VCM1390R .....	8
CLEANING & MAINTENANCE INSTRUCTIONS.....	9
SERVICE & MAINTENANCE.....	9
SPARE PARTS.....	9
WARRANTY .....	9
WARRANTY REGISTRATION.....	11

**WARNING: PLEASE ENSURE THAT ALL SAFETY INSTRUCTIONS ARE UNDERSTOOD BY ALL PERSONS WHO USE THIS APPLIANCE**

**Arabic**

تحذير: تأكد من فهم كل من يستعمل الجهاز لكافة احتياطات الأمان وتعليمات التشغيل.

**Cambodian**

ការព្រមាន: សូមប្រាកដថា គ្រប់អ្នកប្រើប្រាស់ ត្រូវបានពន្យល់អំពីការប្រើប្រាស់ និងការថែទាំ និងការប្រើប្រាស់ បានត្រូវតាមច្បាប់ចម្លងសំណុំសៀវភៅ ទេរាល់អ្នកដែលប្រើប្រាស់នេះហើយ ។

**Chinese**

警告：必需確保任何使用這器具的人士，已明瞭一切安全預防措施及操作指示。

**Croatian**

**Upozorenje:** Budite sigurni da svi koji rade na aparatima znaju o mjerama opreza i funkciji ovih aparata.

**French**

**Attention:** Veuillez vous assurer que toutes les personnes utilisant l'appareil comprennent tous les conseils d'utilisation et précautions de sécurité.

**German**

**Warnung:** Versichern Sie sich, daß alle Sicherheitsvorkehrungen und Bedienungsanleitungen von allen Benutzern des Gerätes verstanden worden sind.

**Greek**

Προειδοποίηση: Βεβαιωθείτε ότι όλα τα προφυλακτικά μέτρα ασφαλείας και οι οδηγίες λειτουργίας κατανοούνται από όλα τα άτομα που χρησιμοποιούν τη συσκευή.

**Italian**

**Attenzione:** assicuratevi che tutti coloro che adoperano i macchinari conoscano le misure di sicurezza e le istruzioni relative al funzionamento.

**Macedonian**

Предупреудање: Осигурајте сите оние кои користат апарати ги разбираат мерките за безбедност и упатства за работа.

**Malay**

**Amaran:** Pastikan bahawa semua langkah keselamatan dan keterangan operasi telah difahami oleh semua pengguna alat ini.

**Polish**

Ostrzeżenie: upewnij się, że wszystkie środki ostrożności i instrukcje obsługi są rozumiane przez wszystkich używających tego urządzenia.

**Portuguese**

Atenção: Assegure-se de que todas as medidas de segurança e instruções de funcionamento são compreendidas por todos aqueles que usam este aparelho.

**Russian**

Предупреждение: Позаботьтесь о том, чтобы все меры безопасности и инструкции по эксплуатации были поняты всеми, кто пользуется этим устройством.

**Serbian**

Упозорење: Водите рачуна да сви који употребавају овај уређај знају мере предострожности и упутства за руковање.

**Spanish**

**Advertencia:** Haga que las precauciones e instrucciones para el uso de este aparato sean entendidas por todos los que lo usan.

**Tagalog**

**Babala:** Siguruhing ang lahat nu mga pangkaligtasang pag-iingat at mga tagubilin hinggil sa pagpapaandar ay naiintindihan ng lahat ng gumagamit ng kasangkapan.

**Turkish**

Uyarı: Tüm güvenlik önlemlerinin ve aygıtı çalıştırma talimatlarının aygıtı kullanan herkes tarafından anlaşılması için çalışınız.

**Vietnamese**

Lưu ý: Chắc chắn rằng những người sử dụng máy đều đã hiểu rõ tất cả các chỉ dẫn về cách vận hành máy và các dự phòng an toàn.

**RETAIN THESE SAFETY INSTRUCTIONS**

## IMPORTANT SAFETY INSTRUCTIONS

Please read all of the instructions before using the Vitacrush blender and ensure that other operators also read and are made to understand all safety and operating instructions. Save these instructions for Future reference.

Thank you for purchasing a Semak Vitacrush Blender.

1. **Important notice:** Ensure that the power supply is switched off before connecting to the electric outlet.
2. Use only on AC 220-240V – 50 Hz only.
3. Do not use an extension cord.
4. To avoid risk of electric shock, do not immerse cord, plug or motor end of the appliance in water or any other liquid. Never put the Vitacrush in a dishwasher.
5. Always switch off at the power outlet before removing the plug. Remove by holding the plug - do not pull on the cord. When the appliance is not in use, or prior to cleaning, always switch off the power and removes the plug.
6. Disconnect power cord from the electrical outlet when the blender is not in use.
7. The Vitacrush blender should not be used by children or infirm persons and care should be taken when used near these persons. The Vitacrush blender should not be used outdoors. Young children should be supervised to ensure that they do not play with the appliance. Never leave the blender unattended.
8. Avoid physical contact with moving parts. The cutting blades are very sharp and **care is needed when handling cutting blades**, and only when the Vitacrush blender is disconnected from the power supply. Never attempt to touch the cutting assembly when the blender is in operation.
9. Never operate the Vitacrush without the container securely in place. Never operate the Vitacrush with an empty container.
10. Do not use on the stove or let the cord come into contact with any hot surface.
11. Keep hands and utensils out of the container while using the Vitacrush to prevent the possibility of severe injury to persons or damage to the unit. A plunger is supplied to aid in getting the contents of the container from the sides to the blades.

12.WARNING: Blade is sharp. Please handle carefully.

DO NOT try to remove blade while the container is sitting on the motor base.

DO NOT operate with loose, nicked or damaged blade replace immediately.

CAUTION keep all utensils AWAY FROM the drive socket and blender blades during operation. Metal utensils will damage blades.

DO NOT place container into drive socket if blender motor is operating.

DO NOT rock the blender during operation.

13.When blending liquids, especially hot liquids, ensure that the lid is on securely and the lid insert is in place to reduce the risk of spillage and injury. Hot liquids build up steam pressure and special care must be given when removing the container and lid from the blender that the contents don't splatter and burn the operator. Keep hands, arms and face away from the lid insert to prevent possible scalding.

DO NOT start blending hot liquids on HIGH speed. Always start processing hot liquids on LOW speed then increase while the machine is running.


14.Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, is dropped or damaged in any way. Return the appliance to Semak Australia. (Manufacturer) or its Authorised Service Agent for repair. **Do not attempt to repair the machine.**

15.For Safety reasons and to avoid maintenance by unskilled persons, the appliance should always be returned to Semak Australia. (Manufacturer) for adjustment or repair if required.

WARNING – This appliance should be used according to the instructions.


MISUSE of this appliance will cause HAZARD.

## BLENDER MODELS



VCE1500B

1	Muddler
2	Measuring cup
3	Lid
4	PC cup
5	Blades assembly
6	Motor base cover
7	LCD information center
8	Control panel



VCM1390R

1	Muddler
2	Measuring cup
3	Lid
4	PC cup
5	Blades assembly
6	Motor base cover
7	Variable speed switch
8	Pulse switch
9	Power switch

## **OPERATING INSTRUCTIONS: VCE1500B & VCE1050B**

The Semak Vitacrush chops, blends and mixes quickly and efficiently. Use it to make sauces, soups, purees etc.

1. Before connecting to electrical outlet, wash the container and its parts and also, wipe the blender base with a damp cloth.
2. Ensure that the power supply is also switched off before connecting to the electrical outlet. Turn the power ON.
3. Turn the blender ON at the switch found at the rear left hand side of the machine.
4. Place the container on the blender. Ensure that the lid and insert are properly located on the container. If a sound cover is being used, close the sound cover before operating the blender.
5. Choose a program e.g. 45, 75 or 105 seconds (timed) or select a speed eg. High Medium or Low. Press the appropriate button. Note if a speed has been selected pressing the pulse button alters the speed of the motor to vary the blending action.
6. Motor cuts off automatically once the timer reaches the desired blending cycle. If using the speed option simply repress the button selected and the blender will stop. To prevent splashing, do not lift the container lid or open the sound cover whilst still in operation.
7. When mixing or blending hot ingredients, the following precautions should be observed:
  - Take care not to lift the lid without checking if pressure has built up in the container. Release pressure slowly by turning the lid insert a little allowing steam to escape and taking care not to burn fingers.
  - Do not stand directly over container of hot ingredients when removing the lid.
  - If necessary allow to stand so that steam escapes slowly.
8. Do not leave the blender unattended or leave contents in the container when not in operation.
9. The blender is overload protected. If the motor gets too hot it will cease to operate. Allow the blender to cool down then reset the overload switch by pressing the button located on the bottom right hand side of the rear of the appliance.
10. If the overload is tripped it may be necessary to modify how or what you are blending e.g. Reduce the amount being blended to smaller amounts or reduce the time selected or add more liquid. Seek advice if necessary.

## **OPERATING INSTRUCTIONS: VCM1390R**

The Semak Vitacrush chops, blends and mixes quickly and efficiently. Use it to make sauces, soups, purees etc.

1. Before connecting to electrical outlet, wash the container and its parts and also, wipe the blender base with a damp cloth.
2. Ensure that the power supply is also switched off before connecting to the electrical outlet. Turn the power ON.
3. Turn the blender ON at the switch found at the rear left hand side of the machine.
4. Place the container on the blender. Ensure that the lid and insert are properly located on the container. If a sound cover is being used, close the sound cover before operating the blender.
5. Turn the ON OFF switch to the on position. Use the variable speed control knob to select the speed that you want to blend at. Use the pulse switch to pulsate the mixture as required.
6. To prevent splashing, do not lift the container lid or open the sound cover whilst still in operation.
7. When mixing or blending hot ingredients, the following precautions should be observed:
  - Take care not to lift the lid without checking if pressure has built up in the container. Release pressure slowly by turning the lid insert a little allowing steam to escape and taking care not to burn fingers.
  - Do not stand directly over container of hot ingredients when removing the lid.
  - If necessary allow to stand so that steam escapes slowly.
8. Do not leave the blender unattended or leave contents in the container when not in operation.
9. The blender is overload protected. If the motor gets too hot it will cease to operate. Allow the blender to cool down then reset the overload switch by pressing the button located on the bottom right hand side of the rear of the appliance.
10. If the overload is tripped it may be necessary to modify how or what you are blending e.g. reduce the amount being blended to smaller amounts or reduce the time selected or add more liquid. Seek advice if necessary.

## **CLEANING & MAINTENANCE INSTRUCTIONS**

Always unplug the Vitacrush blender from the power source before cleaning. The unit is easiest to clean by placing water in the container immediately after completing the blending task and running the blender to dislodge blended mixture. Repeat with fresh water until the water runs clear. Wash with a HACCP detergent and rinse clean for more stubborn soiling.

- A HACCP sanitizer may be used to minimize bacterial contamination.
- Do not place Vitacrush containers in a dishwasher.
- Clean motor wiping with a barely damp cloth only.
- **Never** immerse the motor end, plug or cord in water or any other liquid.
- The **bearing should be lubricated** occasionally with a HACCP approved food grade lubricant by placing a couple of drops at the base of the cutting unit and drive shaft. Spin the blade to assist in the dispersion of lubricant into the bearing.

## **SERVICE & MAINTENANCE**

For Service and Repair, contact Semak for your nearest Authorised Service Agent.

The Foodservice Industry is deemed a hostile environment within the scope of AS/NZS 3760:2003. Semak Vitacrush MUST be routinely electrically tested for compliance with this standard if used commercially.

It is recommended that a Food Safety program such as HACCP be employed and that routine service and repair be undertaken at the time of electrical testing to ensure the correct operation and function of all parts. The equipment MUST be serviced annually or sooner depending of the hostility of the environment in which it is operated.

## **SPARE PARTS**

Spare Parts, exploded views and wiring diagrams are available from our webpage. Go to [www.semak.com.au](http://www.semak.com.au) and locate the appliance in the product section for the above information.

## **WARRANTY**

Semak Vitacrush Blenders are Commercial Grade blenders suitable for commercial use. This product is guaranteed for 12 months from the date of purchase against mechanical and electrical defects. If the fault is deemed caused by MISUSE/ABUSE the terms of the warranty are invalidated. If the product has been opened or tampered with (ie. In an attempt to repair it) the warranty is invalidated.

All warranty repairs should be undertaken by Semak Australia.

It is against company policy to authorize warranty repairs over the phone. Service Agents will require a work order number from Semak to conduct warranty repairs.

# SEMAK® WARRANTY

## THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED AND SOLD IN AUSTRALIA

The benefits conferred by this warranty are an alternative to all other rights and remedies in respect of the product which the consumer has under the Trade Practices Act and similar State and Territory Laws.

Semak Australia. Warrant each new SEMAK appliance manufactured by SEMAK to be free from defects in materials or manufacturing process for a period of 1 Year from the date of original purchase.

Should defects due to faulty materials or manufacturing process develop within the warranty period, the appliance will be repaired without charge providing all conditions of this warranty are observed.

1. Proof of Purchase and Warranty card must be retained and available on request.
2. This Warranty is void if the equipment has been damaged due to misuses neglect or is used for a purpose for which it was not suited; and no repairs, alterations or modifications have been attempted by other than Semak or its authorised Service Agent.
3. Semak Australia. Reserves the right to reject a claim for warranty if service is required due to misapplication, improper installation, inadequate wiring, and incorrect voltage conditions. Under no circumstances shall SEMAK or its agents bear responsibility for consequential damages of any kind.
4. Where required by Statute or local authority, equipment must be installed by qualified person in accordance with all relevant regulations. Failure to do this will void product warranty.
5. Cost of transport of any appliance or part to and from SEMAK or its Service Agent is to be paid by the owner.
6. A charge will be made where failure is due to neglect, abuse or accidental damage on the part of the operator, or when no fault can be found or the fault is due to causes outside the control of Semak Australia.
7. The above does not preclude the purchaser from their Statutory rights as a consumer.

**Semak Australia**  
Factory 18  
87-91 Hallam South Road  
HALLAM VIC 3803

Ph 03 9796 4583  
Fax 03 9796 4586  
Email [technical@semak.com.au](mailto:technical@semak.com.au)  
Web [www.semak.com.au](http://www.semak.com.au)

# WARRANTY REGISTRATION

**Retain for Future Reference**

**DO NOT SEND**

Please complete one registration for each Semak appliance.

You may be required to provide this information when requesting after sales service. Please staple your proof of purchase to this page.

Company Name: \_\_\_\_\_

Company Address: \_\_\_\_\_

Business Type: \_\_\_\_\_

Contact: \_\_\_\_\_

Phone: \_\_\_\_\_

Fax: \_\_\_\_\_

Email: \_\_\_\_\_

Product: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Place of Purchase: \_\_\_\_\_

